

2023/5/19

# **Eye-Gaze Tracking Analysis of Driver Behavior While Interacting With Navigation Systems in an Urban Area**

M2 Morita Hiroto

# Research Overview

- **What This paper study**

- Analyzed the eye-gaze tracking of drivers while interacting with portable navigation systems
- Find out how drivers are affected when the location and size of the navigation system changes.
- Suggested that larger, closer-positioned displays are safer

- **What I Study**

- Finding the optimal position of the wheel loader's sub-display by analyzing eye movement data.

➤ **Therefore, I considered the results of this paper to be helpful in discussing the results of my own research.**



Portable Navigation

Source: [https://m.media-amazon.com/images/I/81Wr6LIKGL.\\_AC\\_SX679\\_.jpg](https://m.media-amazon.com/images/I/81Wr6LIKGL._AC_SX679_.jpg)



KOMATSU WA475-10

from <https://www.komatsu.eu/en/wheel-loaders/wheel-loaders/wa475-10>

# Introduction

- **On-board vs. Portable Navigation Systems**

- Traditional on-board navigation systems are built into the car.
- Portable navigation systems can be moved
  - which can **affect how drivers interact with them.**



On-board Navigation

Source: <https://jpn.pioneer/ja/carrozzeria/carnavi/cybernavi/img/main.jpg>



Portable Navigation

Source: [https://m.media-amazon.com/images/I/81Wr6LIKGL.\\_AC\\_SX679\\_.jpg](https://m.media-amazon.com/images/I/81Wr6LIKGL._AC_SX679_.jpg)

- **Why is this Study Important**

- There are safety guidelines for on-board navigation systems.
- But there are **no guidelines** for portable navigation systems.
  - we don't know the safest way to use these systems while driving.

- **Purpose**

- Understand how drivers interact with portable navigation systems.

# How to Evaluate

- **Eye-Gaze Tracking**

- Eye-gaze tracking analyze where people look.
- It uses cameras and Infrared rays to record gaze direction.
- It helps understand how drivers interact with these systems.
- **Calculated parameters**
  - Glance frequency : How often participants look at navigation system
  - Glance time : Amount of time spent looking at the navigation system

- **Subjective evaluation**

- Drivers rated acceptability, safety, and fatigue for the different conditions.
- They rated these aspects on a five-level scale.

- Based on the above parameters, investigate the impact of different size and location of the navigation system on driver behavior.

# Apparatus

- **Moving-based DS**
  - It can move in six directions, just like a real vehicle.
- **Navigation Systems**
  - Two types of navigation systems were used
    - Portable system (MapFan Navii)
    - On-board system (Carrozzeria).
  - Both systems showed a 2-D map and travel information.
- **Display Sizes**
  - The portable navigation system had two display sizes
    - 4.3 inches and 7 inches.
  - The on-board navigation system only had a 7-inch display.



(a)



(b)

Physical sizes of the (a) 4.3- and (b) 7-in displays.


# Experimental Design

- **Display Positions**

- A': on-board navigation system.
- **3 positions of the portable navigation**
  - A: right side of the built-in navigation position.
  - B: the top of position A.
  - C: the right and upper side of the dashboard.
- Visual angle
  - A: 43, B: 44, C: 26 [deg]

- **Experimental Conditions**

- The study had 7 experimental conditions.
  - 2 display sizes (4.3 and 7 inches) × 3 positions (A, B, C).
  - + On-board navigation system(7inch, A')






# Participants

- **Participants**

- 20 people (men and 4 women)
  - Their ages ranged from 22 to 54 years.
- All participants had valid Japanese driving licenses.
  - They had been driving for an average of 16.4 years.
  - Their average driving frequency was twice a week.

- **Procedure**


- Participants drove seven different routes with different destinations.
- They were not allowed to manually operate the navigation system.
- They only interacted with the system visually to get the correct traffic route.



# Results : Eye-Gaze Tracking

- **Display Position**

- Near position (C) led to
  - Higher glance frequency
  - B < C ( $p = 0.006$ )
  - Shorter glance times
  - C < A & B ( $p = 0.001$ )





➤ It is considered that A & B are safer than C

- **Display Size**

- A smaller display size resulted in longer glance times.
  - 4.3 inch > 7.3 inch ( $p = 0.02$ )

➤ A displays placed in a distant position (A & B) or small-size portable display may increase visual distraction





# Results : Subjective Evaluation

- The five levels of evaluation score were:  
1 = very low, 2 = low, 3 = average, 4 = high, and 5 = very high.


- **Display Size**

- The small-size portable display received lower scores for acceptability and fatigue.

- 4.3 inch indicates significantly **lower acceptability** than 7 inch ( $p = 0.001$ )
    - 4.3 inch indicates significantly **lower fatigue** than 7 inch ( $p = 0.005$ )

- ◆ **Why fatigue score is higher when using 7 inch**


- Glance frequency was relatively higher for the 7-in display than for the 4.3-in display
  - Which means High frequency of glance increases fatigue.



# Discussion

- **Effect of display position**

- Display positions make significant difference in the driver's eye movement.
- Even though all display locations met the guidelines for **in-vehicle display systems**
- **Especially**, longer glance time may result in the driver taking their eyes off the road and an increased risk of collision.



- **Differences of traffic rules**

- This study was conducted for the right-hand driving on the left side of the road in Japan.
- There is little difference in the eye-gaze tracking behavior when the left-hand driving on the right side of the road
- the results of this study may be referenced for wheel loader's sub-display

# Conclusion

---

- **What the Study Find**

- The study found that the size and position of portable navigation displays significantly affect driver's eye-gaze behavior.
- A smaller display size can lead to longer glance times, which may increase visual distraction for drivers.

- **About User Experience**

- The study also conducted a subjective evaluation of the navigation systems.
- Participants found small displays harder to use and gave them lower scores for acceptability and fatigue.

- **What can be used for**

- The study provides insights that can help in creating guidelines for portable navigation systems.
- These guidelines can improve both safety and user experience.